

Non-Surgical Isolation Gowns (T Gown)

SOLUTIONS FOR MEDICAL PROVIDERS AND FIRST RESPONDERS



For removal, tear perforation on back side of gown

FEATURES

- Tested for compliance with ANSI/AAMI PB70:2012 Minimal Barrier Performance Level 1, Level 2 requirements
- Easy to put on and take off
- Back side is marked and perforated for easy removal
- Openings in end of sleeve seal for fingers/hand
- Long sleeve, full coverage
- Made from polyethylene (Virgin LLDPE)

WARNING

- This product is a Class I device and has NOT been FDA cleared or approved.
- This product is NOT intended for antimicrobial or antivirus protection, infection prevention, or infection reduction.
- This product is NOT intended for surgical use.
- This product provides Minimal or Low Barrier Performance Level 1 and Level 2 Protection under ANSI/AAMI PB70:2012.
- This product is NOT sterilized.
- This product is for single use ONLY.
- Do NOT use in the presence of any high intensity heat source or flammable gas.
- This product has been authorized by the FDA under an Emergency Use Authorization (EUA) for use as PPE in health care settings by HCPs as they may help protect HCPs and/or patients from the transfer of the SARS-CoV-2 virus in low or minimal risk level situations to prevent the spread of COVID-19.
- This product is only authorized for the duration of the declaration that circumstances exist justifying the authorization of emergency use of medical devices, including alternative products used as medical devices, due to shortages during the COVID-19 outbreak, under Section 564(b)(1) of the Federal Food, Drug and Cosmetic Act, 21 U.S.C. 360bbb-3(b)(1), unless the authorization is terminated or revoked sooner.

SKU	Model	Neck	Mil	Film Color	Material	Style	Span	Length	Case Pack	Cases/Pallet
Tgown	68 - L	10"	1.5	Blue	Polyethylene	Group Folded	68"	50"	50	84

Manufactured in USA / Patent Pending

For more information contact your Heritage Sales Representative

Follow this link for more information about preparing the gown for use



Non-Surgical Isolation Gowns

DONNING AND DOFFING INSTRUCTIONS



1

Locate the back of the gown, with the print facing the user.

Break the perforation line below each sleeve to separate the sleeves from the body of the gown.

2



3

Open the gown from the bottom, and insert hands into the sleeves.

Push thumbs and fingers through the perforated openings at the end of each sleeve.

4



5

Gather the gown together at the neck opening and slip the entire gown over the head.

Wrap the extra body material to the back side and tie or use an adequate amount of tape to secure.

6



For easy removal, tear along the vertical perforation line on the back.
Doff the gown per CDC guidelines.