



Suma® Dip K1 Liquid Presoak

Alkaline-chlorinated liquid presoak and destainer for china and stainless steel.

Effective

- An alkaline-chlorinate liquid presoak for flatware and utensils
- Effective for the removal of caked-on food
- For use on stainless steel cutlery and aluminum
- Removes stubborn tannin stains left by coffee and tea

Cost-Effective

- Highly concentrated formula provides a more economical use



Suma® Dip K1

Liquid Presoak







Use Directions

- Use this product as directed by your Diversey representative.
- This product is designed to be diluted at a rate of 0.2–4 oz/gal (1.6–31.2 mL/L), depending on the soil load, and is used to presoak stainless and aluminum flatware and utensils, prior to washing in a dishmachine.
- Do not use this product on silver plated flatware, dishware with gold trim, melamine plastics, copper, or brass.
- Cover or remove all food products from the area prior to using this product.
- Do not allow this product or its solutions to splash onto other surfaces. Dilute this product only with water.
- For Food Plant Use: Avoid contamination of food during use or storage. Cookware or utensils and other equipment and surfaces subject to direct contact with food must be thoroughly rinsed with potable water prior to re-use.

Product Specifications

Description	
Certifications	CFIA, Kosher
Color/Form	Straw, liquid
Flash Point	>200° F (> 93.4° C)
pH	12.65 (Concentrate) 11.36 (Use Dilution 1:32)
Scent	Chlorine
Shelf Life	6 months
Solubility	Complete
Specific Gravity	1.097

Available Items

Product Code		Description/Package Size	Dilution
93331251		4 x 1 gallon / 3.78 L Containers	1:32–1:640
3331251			
93331198		1 x 5 gallon / 18.9 L Pail	1:32–1:640
3331198			

Safety Reminder

Please make sure your employees read and understand the product label and Safety Data Sheet before using this product. The label contains directions for use, and both the label and SDS contain hazard warnings, precautionary statements and first aid procedures. SDSs are available on-line at www.sealedair.com or by calling 888 352 2249. Improper use or dilution may result in damage to surfaces and may result in health and physical hazards that match those of the concentrate. Please refer to the Diversey HazMat Library, only available through Internet Explorer, <http://naextranet.diversey.com/dot/>, for up to date shipping information.